

[Click here to get the complete manual](#)

DX35Z

Shop Manual

K1025197E

Serial Number 5001 and Up

DOOSAN reserves the right to improve our products in a continuing process to provide the best possible product to the market place. These improvements can be implemented at any time with no obligation to change materials on previously sold products. It is recommended that consumers periodically contact their distributors for recent documentation on purchased equipment.

This documentation may include attachments and optional equipment that is not available in your machine's package. Please call your distributor for additional items that you may require.

Illustrations used throughout this manual are used only as a representation of the actual piece of equipment, and may vary from the actual item.

DX35Z

Serial Number 5001 and Up

Pub.No. K1025197E



Product Label



Instructions

**Trim Out The Label Along
The Lines And Insert Into
Pocket On The Binder Spine**

Table of Contents

Safety

Track Excavator Safety	SP001061
------------------------------	----------

Specifications

Specification for DX35Z	SP001062
-------------------------------	----------

General Maintenance

General Maintenance Procedures	SP000016
Standard Torques	SP000813

Upper Structure

Cabin	SP001063
Fuel Tank	SP001079
Swing Bearing	SP001064

Lower Structure and Chassis

Track Assembly	SP001065
----------------------	----------

Engine and Drive Train

Drive Coupling (Main Pump)	SP001066
----------------------------------	----------

Hydraulics

Accumulator	SP000028
Center Joint (Swivel)	SP001067
Cylinders	SP001070
Swing Motor	SP000987
Travel Motor	SP000840
Main Pump	SP000864
Main Control Valve	SP001071

Remote Control Valve (Work Lever / Joystick)	SP001072
Travel Control Valve.....	SP000839
Pedal Valve.....	SP001073
Hydraulic Schematic (DX35Z).....	SP001074

Electrical System

Electrical System	SP001077
Electrical Schematic (DX35Z)	SP001078

Attachments

Working Attachments.....	SP001075
Bucket.....	SP001076